


10HP Reciprocating Cube



10HP Reciprocating Cube

Item Number	Parts Description	10hp 1 Phase	10hp 3 Phase 230V	10hp 3 Phase 480V
1	Drive motor mounting plate shaft	IAT-CBMTR-SHFT	IAT-CBMTR-SHFT	IAT-CBMTR-SHFT
2	Drive motor mounting plate	IAT-CBMTR-PLT	IAT-CBMTR-PLT	IAT-CBMTR-PLT
3	Electric drive motor	IAT-L1512T	IAT-EM3714T	IAT-EM3714T
4	Drive motor pulley	IAT-LP2B825	IAT-LP2B875	IAT-LP2B875
5	Drive motor pulley mounting hub	IAT-LPH13/8	IAT-LPH13/8	IAT-LPH13/8
6	Drive belts	IAT-B74	IAT-B74	IAT-B74
7	Oil drain tube	IAT-PF3/8X6	IAT-PF3/8X6	IAT-PF3/8X6
8	Inner stage safety valve	IAT-ST25-70	IAT-ST25-70	IAT-ST25-70
9	Reciprocating pump air filter element	IAT-CA-712114	IAT-CA-712114	IAT-CA-712114
10	Discharge check valve	IAT-CB75	IAT-CB75	IAT-CB75
11	Discharge safety valve	IAT-ST25-250	IAT-ST25-250	IAT-ST25-250
12	Discharge JIC fitting	IAT-2501-12-12	IAT-2501-12-12	IAT-2501-12-12
13	Reciprocating compressor pump	IAT-CA2	IAT-CA2	IAT-CA2
14	Centrifugal unloader elbow	IAT-CA-070400	IAT-CA-070400	IAT-CA-070400
15	Oil sight glass	IAT-CA-731005	IAT-CA-731005	IAT-CA-731005
16	Operational pressure switch	IAT-LF10-1H3	IAT-LF10-1H3	IAT-LF10-1H3
17	Motor starter	IAT-A30CRE45BA5E045	IAT-A30CRE45BA5E045	IAT-A30CFR45CX5E045
18	Motor starter enclosure	IAT-AB1086-HGCK	IAT-AB1086-HGCK	IAT-AB1086-HGCK
19	Belt Guard	IAT-BG-CUBE-V3	IAT-BG-CUBE-V3	IAT-BG-CUBE-V3

Part numbers subject to change/update always consult factory prior to ordering



Compressed Air Systems, LLC

2626 Skyway Drive
Grand Prairie, TX, 75052

Simplicity. It's What We Do.

Parts Department hours:

Monday-Friday 8:00 - 5:00 CST

1-800-531-9656

Fax 972-352-6364